

## JEEP WRANGLER JL / JLU & GLADIATOR JT OUTER COWL COVERS

*P/N: 6923 / 6923PC / S6923*  
INSTALLATION INSTRUCTIONS

Note: Installation does not require the use of any sealant, but you may utilize some silicone or RTV sealant between the cowl covers and the body to keep out the elements. We highly recommend spraying any exposed metal or drilled holes with primer before installing your cowl covers to keep rust from becoming a problem later.

The Warrior 6923 series Outer Cowl Covers should be installed with a small gap on all sides and requires some massaging to get it into place. Once the cover lays flat against the body and is shaped to conform to the body, there should only be a small gap on all sides.

During shipping, boxes can be stacked on top of these Outer Cowl Covers causing them to get slightly bent. We recommend test fitting the product first. If the fitment is not ideal, simply lay some cardboard on the ground and bend the product to match your vehicle's body.

Tools required:

Marking Pen  
Hand Drill  
3/16" Drill Bit  
Pop Rivet Gun

Sealant (if desired)  
T40 Torx  
5mm Allen Key / Bit



**INSTALLATION:**

1. Begin on the driver side of the vehicle. The vehicle has 2 screws attaching the factory cowl panel to the vehicle. The bolt closest to the front of the vehicle protrudes slightly and will not allow the Cowl Cover to sit flat. Using the T40 Torx to remove this screw.
2. Replace the Torx screw you just removed with the slightly smaller 8mm button head screw and washer provided, using a 5mm Allen key.
3. Set and hold the cowl cover against the Jeep and visually align the edges around the perimeter so that the spacing is symmetrical.
4. While holding the cover in place, use a marking pen and designate where the two inner edge holes will be drilled (closest to the inner cowl).





Warrior, Inc.  
11100 SW Industrial Way  
Tualatin, OR 97062  
Phone: (888) 220-6861  
Fax: (503) 692-0364

[customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com)  
[www.warriorproducts.com](http://www.warriorproducts.com)

- 
5. Set the cover aside and carefully drill out the holes you just marked, using a 3/16" drill bit.
  6. Set the Cowl Cover in place to confirm fitment. Apply silicone or sealant at this time if you have chosen to do so as part of the installation. It is not required.
  7. Pop rivet the upper edge into place, then push and hold the lower edge against the Jeep body. Make the two outer holes by drilling through the mounting holes in the cowl cover and into the Jeep body.
  8. Pop rivet the outer edge into place. Repeat steps for passenger side.

If you need further assistance installing your product, please contact us by email at [customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com) or call us at (888) 220-6861.

**THANK YOU FOR PURCHASING WARRIOR PRODUCTS**



**WARRIORPRODUCTS.COM**

