

Trailblazer Rocker Guard

Rocker Guard Shown



Drilling and Mounting Location

PART NUMBER
42-4035

REQUIRED TOOLS
<ul style="list-style-type: none"> • Ratchet and Socket Set • Torque Wrench • Drill, 5/16" Drill Bit

PARTS	
QTY	PRODUCT
1	Rocker Guard Set (Left and Right)
16	3/8" x 1" Self Tapping Bolts

WARRANTY
3 YEARS

INSTRUCTIONS:

1. Position the guard up to the frame. Maintain a 1/2" minimum gap between the bottom of the vehicle and the top of the guard. Adjust the Trailblazer Rocker Guard from front to back until it is parallel to the side of the frame while also making sure it is parallel with the side of the vehicle. (Assistance is recommended while installing these guards)
2. When you are satisfied with the placement of the Trailblazer Rocker Guard, mark the side of the frame through the mounting holes located on the Trailblazer Rocket Guard brackets. After you have marked all the holes place the guard to the side. Center punch the frame at the marked locations and drill a 5/16" hole in the frame. Caution: Before drilling be sure to check the backside for hazards or obstructions.
3. Position the Trailblazer Rocker Guard back against the frame and line up the holes in the brackets with the holes that you just drilled on the frame. Secure the Trailblazer Rocker Guard to the frame using the supplied self tapping bolts. Tighten all bolts at this time to 10-15 ft/lb (Figure 1).
4. Repeat these steps to install the other side. Installation is now complete.