

.....  
**Warrior, Inc.**

# **SIDE PANELS**

## **DIAMOND PLATE / STEEL**

All “SIDE PANELS” are designed to be placed over the existing metal surface. They fit between the fender wells with factory fenders and fender flares where applicable.

- 1) Be sure that the surface is flat before installing your side panels. Put some paint on any bare metal.
- 2) Lift one side panel up to the rocker panel and use it to determine where you want to place your mounting holes. Mark the mounting locations with a felt pen or other marker and remove for ease of drilling. If you are covering rust or damaged areas, try not to locate any mounting holes in these areas.
- 3) If using the “pop” rivets provided to attach your side panels, you will need to secure a drill, a 3/16” drill bit, and a “pop” rivet tool. Drill your mounting holes using the 3/16” drill bit.
- 4) Place your drilled side panel in location and mark through the holes onto the rocker panel. Drill mounting holes where indicated using your 3/16” bit. Be careful not to drill through anything that may be behind the rocker panel.
- 5) Install the side panels using the “pop” rivets supplied. If you prefer you can use self tapping bolts to install the panels.
- 6) Repeat the process described above for the other side.

**CONGRATULATIONS! You have finished your installation. Enjoy your new Warrior Products Side Panels and be sure to look for other quality Warrior Products for your vehicle.**

.....  
*“Your Knight in Shining Armor!”*