

CFE PRODUCTS
1485 WILMINGTON PIKE
WEST CHESTER PA. 19382
610-358-1886

JEEP CJ & WRANGLER
HARD TOP LIFT GATE
LOCKING ROD
MODEL: JW -JK- HTWR



REV 2011

*CAREFULLY READ ALL INSTRUCTIONS
BEFORE PROCEEDING WITH ASSEMBLY AND
OPERATION !*

The rear window lift gate MUST be secured in the closed position or damage to top may occur while positioning the hard top onto the cart. This is a mandatory procedure. It is highly recommended to purchase the Lift gate Locking Rod #12020.351 to secure the rear window.

1. Place the hard top on the floor with the back end resting on the end blocks.
[The rear window must not contact the end blocks.] BEFORE PROCEEDING the rear window MUST be locked or clamped before placing the top into position. YOU CAN PURCHASE THE OPTIONAL LIFT GATE LOCKING ROD FROM QUADRATEC MODEL # 12020.351

LIFT GATE LOCKING ROD INSTALLATION INSTRUCTIONS

1. The lift gate locking rod must be installed before the hard top is removed from the Jeep.
2. The tail gate must be opened first, and all bolts securing the hard top must be removed.
3. Position the locking rod as shown in fig. # 1 & 2 squeezing the rod and the rear window together, rotate the rod so the yellow end cap ends up on the outside of the window .
4. Make sure that the yellow caps on the end of the rod are positioned as shown in fig.# 3.



ANY COMMENTS OR QUESTIONS ? CALL BOB 610-358-1886