



Protecting Your Adventure Lifestyle

Warrior Products, Inc.  
16850 SW Upper Boones Ferry Rd  
Ste. A  
Durham, OR 97224  
Phone (888) 220-6861  
Fax (503) 692-0364  
sales@warriorproducts.com

---

---

## **GUTTER MOUNT SAFARI RACK**

### **INSTALLATION INSTRUCTIONS**

### **WAR 835 / 835-1**

### **Read all instructions before proceeding.**

**Your Cherokee must have rain gutters full length on both sides of the vehicle for this rack to mount properly. The suggested weight capacity is 400 lbs., with weight distributed evenly over the entire area of the rack.**

1. Assemble the four (4) gutter brackets per the sample already assembled in your kit.
2. Install gutter brackets on Jeep gutters starting with the rear first. Top holes of brackets should be approximately 22" from the rear of the Jeep.
3. Install forward gutter brackets approximately 36 \_" forward from the center of top mounting holes.
4. Tighten carriage bolts until clamps are tight on the gutters at all four corners.
5. Lift basket in place on top of the brackets and then adjust basket to center; forward to back and left to right. Then mark each cross tube where it crosses the cross bar so each cross tube can be drilled. Remove basket for drilling. Use a 3/8" drill bit to drill a total of 8 holes.
6. Reinstall basket using the eight (8) bolts, washers, and nuts provided. Tighten securely.
7. Check tightness of the carriage bolt before tightening the 1" bolts on the gutter brackets.
8. After a test drive, re-check tightness of all bolts and your done!

**Enjoy your new Safari Rack by Warrior!**

If you need further assistance installing your product, please contact us by email at [techsupport@warriorproducts.com](mailto:techsupport@warriorproducts.com) or call us at (888) 220-6861.

**THANK YOU FOR PURCHASING WARRIOR PRODUCTS**

**QUALITY • INTEGRITY • INNOVATION • SERVICE**