



## Instructions for Mounting the Moab in CJ/YJ Jeeps ®

1. Remove the stock seat and bracket from the existing floor pan.
2. Separate the stock seat from the stock bracket by removing the bolts that attach the seat to your stock sliders.
3. Mount your Corbeau Moab seat to the stock bracket and slider using the 4 bolts provided. Locate the correct mounting pattern by placing the bracket on the seat and positioning the bracket so the four holes in the track align with the four mounting holes. The bracket should be positioned in the center of the seat.
4. Re-Install your stock bracket and Corbeau Moab seat to the floor pan. Use the stock bolts and bolt holes to secure the bracket to the floor pan.
5. Be sure that all bolts are secured tightly before operating your vehicle.

### **DISCLAIMER**

*No warranty or representation is made as to this product's ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this product are directly related to the manner in which it is installed used and/or maintained.*

Jeep® is a registered trademark of The Daimler Chrysler Corporation