


## 1955 – 1975 JEEP CJ5 ADVENTURE DOORS

### INSTALLATION INSTRUCTIONS

P/N: 90854

1. This earlier CJ5 did not have door hinges. In this kit hinges are supplied. You should find in your kit two long and two short hinges. The long hinges are for the top, short for the bottom.
2. Begin by locating the top hinge. Attach the hinge to the side of the Jeep, so that the top edge of the hinge bracket is at the bottom edge of the windshield hinge (see diagram to right). Alternatively, you can locate the hinges on the inside of the doorjamb so that they point out sideways. This may make drilling and bolting them in much more difficult on the top hinge however. The edge of the hinge tube where it meets the hinge bracket should sit right at the edge of the doorjamb. Once located, mark and drill holes and bolt into place.



3. You will locate the bottom hinge in the same manner. The key to proper installation is the spread between hinges is 13" measuring at the top of the tube on each hinge piece. See diagram to right.
4. Assemble the supplied latches into the tube doors. Use the hardware supplied with the door handles to screw them into place. To be sure that you've got the correct door on each side, refer to the small plate near the bottom. There is a "WP" logo stamped into them. These should be readable from the outside of the vehicle. You can reference these to determine which door is passenger, and which door is driver.
5. With the door handles now installed into the doors, slide them into the hinges you've installed.
6. Locate your striker pins and striker L brackets. Attach the pin to the bracket in the large oblong hole using a flat washer on each side of the bracket, a lock washer, and hex nut. The pins should sit on the bracket so the round portion is facing away from the mounting holes. These brackets are made to be left and right versions and you will notice that they are around twice the width of the top of your tub.



Warrior, Inc.  
11100 SW Industrial Way  
Tualatin, OR 97062  
Phone: (888) 220-6861  
Fax: (503) 692-0364

[customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com)  
[www.warriorproducts.com](http://www.warriorproducts.com)

- 
7. These will mount on the tub so that they overhang to the inside of the Jeep. You will need to snap the pin into the door latch on the door and align it in a spot that it will open and close comfortably. Make sure that the head of the pin sits in the door latch in a comfortable place and mark and drill holes to bolt it into place.
  8. With the striker plates now in place, close the door latch onto the striker pin to check alignment. Loosen the striker pin and adjust as needed.
  9. To eliminate any door rattle associated with the door latches spring mechanism, we recommend adding a rubber bump stop of some sort (check with your local hardware store) to the door somewhere that it will come into contact with the doorjamb.

If you need further assistance installing your product, please contact us by email at [customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com) or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS



**WARRIORPRODUCTS.COM**

