



Warrior, Inc.  
11100 SW Industrial Way  
Tualatin, OR 97062  
Phone: (888) 220-6861  
Fax: (503) 692-0364  
[customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com)  
[www.warriorproducts.com](http://www.warriorproducts.com)

---

## 1976 – 1983 JEEP CJ5 ADVENTURE DOORS

### INSTALLATION INSTRUCTIONS

*P/N: 90855*

1. Assemble the supplied latches into the tube doors. Use the hardware supplied with the door handles to screw them into place. To be sure that you've got the correct door on each side, refer to the small plate near the bottom. There is a "WP" logo stamped into them. These should be readable from the outside of the vehicle. You can reference these to determine which door is passenger, and which door is driver.
2. With the door handles now installed into the doors, slide them into the hinges.
3. Locate your striker pins and striker L brackets. The bracket has L shaped holes to mount to the tub. Attach the pin to the bracket in the large oblong hole using a flat washer on each side of the bracket, a lock washer, and hex nut. The pins should sit on the bracket so the round portion is facing away from the mounting holes. These brackets are made to be left and right versions and you will notice that they are around twice the width of the top of your tub.
4. These will mount on the tub so that they overhang to the inside of the Jeep. To mount the 90855, existing soft top bolts and bolt holes can be used. These bolt into the same location as the Soft tops soft door striker plate. You must remove the rear side windows, soft door striker and rotate the loose window mount mechanism up out of the way. You should be able to Velcro it inside the soft top.
5. With the striker plates now in place, close the door latch onto the striker pin to check alignment. Loosen the striker pin and adjust as needed.
6. To eliminate any door rattle associated with the door latches spring mechanism, we recommend adding a rubber bump stop of some sort (check with your local hardware store) to the door somewhere that it will come into contact with the doorjamb.

If you need further assistance installing your product, please contact us by email at [customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com) or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS



**WARRIORPRODUCTS.COM**





Warrior, Inc.  
11100 SW Industrial Way  
Tualatin, OR 97062  
Phone: (888) 220-6861  
Fax: (503) 692-0364  
[customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com)  
[www.warriorproducts.com](http://www.warriorproducts.com)

---



**WARRIORPRODUCTS.COM**

