AMERICAN OUTLAW L.L.C.

Jeepers x/s

OUTLAW MIRRORS



American OutLaw does not recommend the removal of your vehicle doors. In the event of an accident, serious injury or death may occur. If you decide to do so the OutLaw Mirror system will give you a better view of your surroundings, allowing you to make better decisions. As with all mirrors there are blind spots, please take the time to identify them. DO NOT rely solely on our mirrors. Keep your eyes moving at all times, Be safe, Have fun and Thank you for your interest in **American OutLaw** products.

INSTALLATION

- 1. Loosen nuts at the bottom of your door hinges and put them in a safe place. Open vehicle door, slide the lower door strap up and off the hook and slid door upward. Place in a safe area. Repeat steps on the other door.
- Place the slotted end of the mirror bracket over the remaining upper door hinge and lower until it seats flush with the bottom hinge.
- 3. Tighten set screw with a 4mm wrench (included) until snug. Do not over tighten!
- 4. Adjust mirrors. Identify blind spots
- 5. Pull fuse to disable door jam switch (see owners manual) Dome light will operate on timer.

SPECIAL INSTRUCTION

- ** Snorkels can be used with OutLaw Mirrors by simply adding 1 in spacers on the windshield bracket, adjusting the stack in a forward direction
- *** If you have a light bar installed on your vehicle with windshield mounts, replacing the lowest windshield bolt with a matching set screw that sits flush will solve the problem.

OutLaw Mirrors for 2007 and newer Jeeps may need to flatten the nylon tip on the set screw before first application,

Visit us at www.americanoutlawjeepparts.com

