

TERAFLEX

INSTALLATION GUIDE

Installation Guide for the TJ RockGuard Front Bumper Part #004666164



Installation:

1. Remove the front factory bumper. Keep track of all the original fasteners.
2. Lift the new TeraFlex RockGuard bumper into place and install with the original factory hardware. Reinstall bolts in the same location as with the stock bumper.

Note: *If you are installing the optional D-Ring Shackle mount it must be installed before the bumper is lifted into place.*

D-Ring Mount (sold separately) Part #004603300

Shackle (sold separately) Part #004802100

Tera Manufacturing, Inc.
5251 South Commerce Dr.
Murray, Utah 84107
Phone/801.288.2585
Fax/801.713.2313
www.teraflex.biz



2006 TJ with optional winch, D-Ring mounts and optional shackles.