



3651 N Highway 89 • Chino Valley, AZ 86323
(928) 636-7080 • www.p-a-g.net

JEEP WRANGLER, RUBICON, UNLIMITED ROCK DOOR KIT INSTALLATION INSTRUCTIONS

1980-1986 CJ

1987-1995 YJ

1997-2006 TJ

2007 JK

KIT# 88001

KIT# 88000

KIT# 88002

⚠ WARNING

Before you install this kit, read and understand all instructions, warnings, cautions, and notes in this instruction sheet and in the vehicle owner's manual.

⚠ CAUTION

Proper installation of this kit requires knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle. We strongly recommend that a certified mechanic familiar with the installation of similar components install this kit.

⚠ WARNING

Always wear eye protection when operating power tools.

⚠ WARNING

Before you install this kit, block the vehicle tires to prevent the vehicle from rolling.

Before Starting Installation

NOTE

Kit parts are prefaced by the word *kit* and appear in **bold** print.

1. Carefully read all warnings and instructions completely before beginning.

2. Verify all parts have been received in this kit by checking the parts list at the end of this document.

NOTE

If parts are missing from kit, please be prepared to provide the following information:

1. **Name** of purchase location
2. **Bar Code** on side of box
3. **Date** above bar code
4. **Date** inside box cover
5. **Inspector #** from inside box cover

3. **Only install this kit on the vehicle for which it is specified.** If anytime during the installation you encounter something different from what is outlined in the instructions, call technical support at (928) 636-7080.

4. Park vehicle on a clean, dry, flat, level surface and block tires so vehicle cannot roll in either direction.

Inside Cab


NOTE

The location of the interior door light switch fuse may vary; check the owner's manual.


1. Open glove box and remove interior door light switch fuse from fuse panel.

Prepare to Install Rock Doors

1. Driver door
 - a. Remove two nuts from two O.E. door hinges.




- b. Open door and remove door restraint strap from pin and vehicle.



- c. **JK Models:** Unplug wire harness to each door.
- d. With door open, lift up and remove O.E. door from two hinges and vehicle.
- e. Repeat above substeps for passenger side door.

- b. **JK Models:** Install two *kit hinges* onto *kit door* (driver) with four *kit bolts* (5/16 x 1" button head). Snug, but DO NOT TIGHTEN.



- c. Install *kit cap* onto *kit door* (driver).


NOTE
CJ, YJ, TJ models require one *kit cap* per door and JK models require two *kit caps* per door

- d. Install *kit plug* onto *kit door* (driver).


Install Rock Doors

1. Driver door


- a. **CJ, YJ, TJ Models:** Install *kit hinge* onto *kit door* (driver) with *kit bolt* (3/8"-16 x 1"), *kit washer* (3/8" SAE), and *kit nut* (3/8"-16 flange). Snug, but DO NOT TIGHTEN.



CJ, YJ, TJ Models



JK Models




- e. Install *kit door* (driver) onto two O.E. hinges with two *kit bolts* and four *kit washers* (nylon)

CJ, YJ Models:


- h. Temporarily install *kit latch* (driver) onto *kit door* (driver) with three *kit bolts* (1/4"-20 x 1"). DO NOT TIGHTEN.

NOTE
CJ, YJ, TJ models: *kit bolts* (3/8"-16 x 3-3/4") and *kit washers* (3/8" nylon)
JK Models: *kit bolts* (7/16"-14 x 3-3/4") and *kit washers* (7/16" nylon)




- f. Install two *kit washers* and two *kit nuts* onto two *kit bolts*. DO NOT OVERTIGHTEN.


NOTE
CJ, YJ, TJ models: *kit washers* (3/8" nylon) and *kit nuts* (3/8"-16 Nylock) onto *kit bolts* (3/8"-16 x 3-3/4").
JK Models: *kit washers* (7/16" nylon) and *kit nuts* (7/16"-14 Nylock) onto *kit bolts* (7/16"-14 x 3-3/4").




- g. Adjust *kit door* (driver) and TIGHTEN *kit bolts*.



- i. Position center of *kit latch* (driver) with door catch on body. Space *kit latch* accordingly with *kit washers* (1/4" SAE).




- j. Install *kit latch* (driver) onto *kit door* (driver) with three *kit bolts* (1/4"-20 x 1"), three *kit washers* (1/4" SAE) and any additional *kit washers* (1/4" SAE) to set *kit latch* to catch.



- k. Adjust *kit latch* (driver), TIGHTEN *kit bolts* (1/4"-20 x 1") and test *kit door* (driver). Readjust *kit latch* (driver) as necessary to obtain proper latch with catch.

TJ Models:


- l. Install *kit latch* (driver) onto *kit door* (driver) with two *kit bolts* (1/4"-20 x 1") and two *kit washers* (1/4" SAE). DO NOT TIGHTEN.



- m. Adjust *kit latch* (driver), TIGHTEN *kit bolts* (1/4"-20 x 1") and test *kit door* (driver). Readjust *kit latch* (driver) as necessary to obtain proper latch with catch.

JK Models:

- n. Install *kit latch* (driver) onto *kit door* (driver) with two *kit bolts* (1/4"-20 x 1"), two *kit spacers*, and two *kit washers* (1/4" SAE). DO NOT TIGHTEN.



- o. Adjust *kit latch* (driver), TIGHTEN *kit bolts* (1/4"-20 x 1") and test *kit door* (driver). Readjust *kit latch* (driver) as necessary to obtain proper latch with catch.



All Models:

- p. Open and close *kit door* (driver) ensuring proper *kit latch* (driver) operation.

NOTE
Kit latches have two stages. The first stage will result in *kit doors* not seated completely against *kit plug*. The second stage will properly seat the *kit doors* against the body. Adjust *kit latches* and *kit hinges* if the second stage is not attainable.

- q. Install **kit weatherstrip** onto **kit door** (driver). Cut **kit weatherstrip** if necessary for proper fitment.

- t. Install **kit pad** (cover, driver) onto **kit pads**. Adjust as necessary.



- u. Repeat above substeps for passenger door.

After Completing Installation

Miscellaneous

1. Check all fasteners to ensure they are tight.
2. Ensure all wires, hoses, cables, etc. are properly connected and there is ample slack.


- r. Install **kit pad** (long) onto upper bar of **kit door** (driver).
- s. Install **kit pad** (short) onto lower bar of **kit door** (driver).

⚠ WARNING

This product is for Off-Road use only. It is NOT intended as a safety restraint device. Always make sure all occupants are wearing seat belts at all times.

NOTE

All warranty information, instruction sheets, and other documents regarding the installation of this product must be retained by the vehicle owner. Information contained in the instructions and on the warranty card will be required for any warranty claims. The vehicle owner needs to understand the modifications made to the vehicle and how they affect vehicle handling and performance. Failure to provide the customer with this information can result in damage to the vehicle and severe personal injury.



Kit Parts List

Qty. Description

| | |
|----------|--------------------------------------|
| 1 | Door (driver) |
| 1 | Door (passenger) |
| 1 | Label (logo) |
| 2 | Label (warning) |
| 1 | Pad (cover, driver) |
| 1 | Pad (cover, passenger) |
| 2 | Pad (long) |
| 2 | Pad (short) |
| 1 | ZH25 (Hardware bag, 88000) |
| 4 | Bolt (1/4"-20 x 1") |
| 2 | Bolt (3/8"-16 x 1") |
| 4 | Bolt (3/8"-16 x 3-3/4") |
| 2 | Cap |
| 2 | Hinge |
| 1 | Latch (driver) |
| 1 | Latch (passenger) |
| 2 | Nut (3/8"-16 flange) |
| 4 | Nut (3/8"-16 Nylock) |
| 2 | Plug |
| 4 | Washer (1/4" SAE) |
| 12 | Washer (3/8" nylon) |
| 2 | Washer (3/8" SAE) |
| 2 | Weatherstrip |
| 1 | ZH26 (Hardware bag, 88001) |
| 6 | Bolt (1/4"-20 x 1") |
| 2 | Bolt (3/8"-16 x 1") |
| 4 | Bolt (3/8"-16 x 3-3/4") |
| 2 | Cap |
| 2 | Hinge |
| 1 | Latch (driver) |
| 1 | Latch (passenger) |
| 2 | Nut (3/8"-16 flange) |
| 4 | Nut (3/8"-16 Nylock) |
| 2 | Plug |
| 24 | Washer (1/4" SAE) |
| 12 | Washer (3/8" nylon) |
| 2 | Washer (3/8" SAE) |
| 2 | Weatherstrip |
| 1 | ZH28 (Hardware bag, 88002) |
| 4 | Bolt (1/4"-20 x 1") |
| 8 | Bolt (5/16" x 1" button head) |
| 4 | Bolt (7/16"-14 x 3-3/4") |
| 2 | Cap (urethane) |
| 4 | Hinge |
| 1 | Latch (driver) |
| 1 | Latch (passenger) |
| 2 | Nut (7/16"-14 Nylock) |
| 4 | Plug (plastic) |

| | |
|---|-----------------------------|
| 4 | Sleeve |
| 4 | Washer (1/4" SAE) |
| 8 | Washer (7/16" nylon) |
| 2 | Weatherstrip |

Copyright 09/06
Performance Automotive Group
www.p-a-g.net