



# JLU 4DR (2018-23) Installation Instructions

\*Updated instructions with photos coming soon\*

## Tools Needed

Plastic trim tool, and optional trim clip pliers

<https://www.harborfreight.com/nylon-pry-bar-installer-kit-4-piece-63594.html>

<https://www.harborfreight.com/panel-clip-pliers-63699.html>

Small flathead screwdriver

10mm socket

16mm wrench

T50 Torx



## Front & Rear Flooring

Step	Description
1	Disconnect battery.
2	If not removing the front seats, protect seat pivot side shields, with tape or cardboard to prevent scratches while handling seat.
3	Remove front and rear floor mats.
4	Remove front sill trim, first remove the door harness/tether panel by prying the edge closest to you then pulling it to the rear of the vehicle. Utilizing a trim tool or small smooth flathead screwdriver, disconnect the door wire harness connector by lifting the red tab up and swinging the white lever down 180 degrees like a switch and unplug the connector. Unhook the tether strap from the hook and place harness in the door panel storage net.
5	Using a trim tool pry away the body side of the door connector/harness from the body.
6	Remove sheetmetal nut using a 10mm socket.
7	Using a trim tool gently pry the front door sill trim towards the inside of the vehicle. Popping it loose, work the panel out evenly.
8	Where the tail of the front trim panel overlaps the B pillar trim, use a trim tool to separate the 2 clips in an upward motion.
9	Once free, guide the trim panel around door tether hook and remove from vehicle.
10	Unbolt the front seat, 2 Torx T50 in front and 2 Torx T50 in back
11A	<b>IMPORTANT NOTICE:</b> You can either tilt the seat forward or rearward to do the remaining tasks. If you wish to remove the seat you will need to unhook the electrical connections including side impact airbag, following the factory manual for proper removal is advised. Not following proper removal procedure could result in serious harm or even death through the accidental discharge of the airbags.
11B	With the seat positioned forward or removed, remove the B pillar trim.
12	To remove the B pillar trim first remove lower seat belt cover panel by using a trim tool to pry towards the middle of the vehicle. Verify the 2 plastic clips are still attached to the cover.
13	Grasp the top portion of the B Pillar trim where the seatbelt goes behind it, gently pull away towards inside of vehicle. With hands behind the trim as you go, attempt to support close to the next clips as you pop the panel free. Work your way to the bottom. Once free, verify the clips are all still attached to the trim, and nothing is broken. In the rare instance a portion breaks, it is advised you replace the panel.
14	Guide seatbelt through slot in bottom of the trim and remove the trim from the vehicle, it is <u>not</u> necessary to unbolt seatbelt.

## Front & Rear Flooring (cont.)

Step	Description
15	Using a trim tool or flathead screwdriver, remove the console bolt covers , 2 front, 2 rear. Using a 10mm socket unscrew bolts and place in a tray to reuse later.
16	Gently lift up on the console, but do not remove.
17	Remove front and rear carpet.
18	<b>IMPORTANT STEP:</b> Remove the plastic floor mat posts and washers by unscrewing with a 16mm socket or wrench, 2 are located in each of the front floor boards and 2 located in the rear, do not worry about the threaded post left behind, the Armorlite floor is designed to work with it in place and will not affect fit or wear. Not removing the plastic caps will result in misalignment of the floor, causing plugs to not fully install or stay in place.
19	Install the Armorlite front flooring.
20a	It is advised to direct the front floor under the center portion of the dash first using a trim tool to guide it up into place under the edge of the dash. Also guiding the holes over the hold down studs.
20b	Then lay the rest of the floor down onto the sheetmetal, run your hand around the perimeter making sure no brackets or wire harnesses are preventing the floor from aligning into place.
21	<b>IMPORTANT STEP:</b> Verify that the floor drain plug openings are perfectly aligned to the drain plug hole. You should see an even sliver of the sheet metal in the opening. Repeat step 20 if hole does not align, do not proceed until these are aligned.
22	<b>IMPORTANT STEP:</b> Once your front floor is aligned in position insert the drain plugs into the holes with the lid open, use considerable force to evenly work plug into the sheetmetal. Be sure to get 2 ribs evenly through the metal, use your finger through the hole to verify, in some cases you can see from underneath or from the vantage of just under the rocker panel using a flashlight. <u>Plugs should not be easily removed if installed properly.</u>
23	If not done already, remove rear bench seat, consult factory manual for procedure.
24	Install the rear flooring.
25	With seats move forward out of the way, or removed. Start with positioning the rear flooring across the vehicle, align slits in floor to the back seat floor brackets and slide the rear floor back. As an option you can unbolt rear seat and lift up securing with seat belts.
26	One rear of floor is in place put one hand down on the center of the rear Armorlite floor holding it down while your other hand or a partner lifts up on the console. Once the console is above the floor set it back down into position.
27	Follow the perimeter of the rear floor pushing it down firmly into place making sure nothing is impeding it from sitting into place. Align the drain plug opening ensuring an even sliver of the sheet metal floor is showing.
28	Install plug following step 22.
29	Proceed to installation of Wheelhouse covers, if you did not purchase wheelhouse covers skip to step 40.

## Wheelhouse Covers

Step	Description
30a	Remove cargo eyelets and panel, first pry up center of cargo eyelet to uncover bolt, using Torx remove bolts, remove eyelets and carpeted panel they reside in.
30b	If you have a Mopar trail rail system remove bolts and remove entire rail.
31	Remove rear section of door sill trim.
32	Remove carpet wheelhouse covers.
33	Install Armorlite Wheelhouse covers, feeding them through seat belt and tucking under rear plastic trim.
34	If you have a subwoofer model insert front part of trim in behind the plastic trim and work around getting it underneath.
35	Wheelhouse cover should overlap the previously installed rear floor at the bottom of the door sill opening.
36	Reinstall rear portion of door sill trim.
37	Install Cargo tie down panel or trail rail system in reverse order of removal, these panels are designed to overlap the wheelhouse cover and hold in place.
38	Install grommets at hole openings on wheelhouse covers snapping over the plastic studs.
39	Proceed to cargo mat installation.

## Cargo Mat & Closeout

Step	Description
40	Install closeout panel under the rear seat, if you have a factory cloth model and do not have the flipper no modification will be needed, your cargo mat will overlap the closeout making continuous coverage.
41	If you have a factory leather model and have the spring loaded flipper you will need to cut the back portion of the closeout off and tuck it under the flipper flange, same as the carpet was installed in this position.
42	Again if you have the factory leather model your cargo mat will need to stop at the back side of the flipper panel. You will need to cut the straight scribe line across the front of the cargo mat.
43	Insert side by side comparison of cloth and non cloth models with highlighted sections. (illustration coming soon)
44	Once installed be sure the cargo mat is in the proper location and not too far back which would interfere with the tailgate and cause issues closing in the future.
45	Reinstall B Pillar trim by orientating panel to align the clips to the holes in the sheetmetal. Push into place using light taps to engage clips. If clips do not go in easy, use a flashlight and carefully and visually watch them line up before applying pressure.
46a	Bolt down center console, you may need to apply pressure down on the rear of the console to align bolt holes before installing. Finish the installation in reverse order of removal.
46b	Install front door sill trim, inspect the clips on the back side and familiarize your self with where and how they attach to the vehicle, if clips are in place and in good shape position trim into place starting with the front going over the door tether and the bolt stud, then connect the rear 2 clips to the B pillar trim engaging those in a downward motion, then aligning clips pull trim toward the outside of the vehicle into position giving it light taps and working your way to the front. Make sure the bottom of the trim makes it over the bead in the Armorlite floor.
47	Install sheet metal nut with 10mm socket, then clip body harness back into sheet metal, take door harness attach tether then make electrical connection same as removal.
48	Position seats into place and reinstall bolts to factory specs.
49	Test that door electronics are functioning correctly and close, be sure seat moves as it should.
50	Taking smooth side of grommets, click them through the holes onto the studs at the top of the transmission hump, and at front of floors.
51	<b>Put hands on hips and enjoy looking at your freshly installed Armorlite floor, wipe forehead and enjoy beverage of your choosing.</b>