

# Jeep CJ7/YJ Adaptor Mounts (C32)

Install Instructions



Driver Side Pictured

**Read through all of the instructions completely before beginning the install.**

**Parts Included:**

- 2, Passenger or Driver Side Mount Plates
- 4, 5/16" X 3/4" bolts
- 4, 5/16" lock nut
- 8, 5/16" Washers
- 4, 3/8" lock nuts
- 4, 3/8"x 1" Bolts
- 8, 3/8" Washers

**Remove all parts from the box and unwrap completely using the packaging to lay out the pieces.**

**Time:**

Approx 30 minutes.



1. Remove Stock seats from the factory sliders by removing the four bolts under each seat (picture A).

### Drivers Side

2. Using four 5/16" bolts loosely install the PRP mounting adaptors to the factory sliders (picture B). Do not fully tighten to allow for adjustments.

Note: the tabs face downward at the back of the mount and upward at the front.

### Passenger Side

3. Place the angle gusset with the rear tab on the edge of the bracket on the door side. The bracket with the rear tab in the center of the mount goes towards the inside of the vehicle.
4. Using Four 3/16 bolts install PRP seat onto mounting adaptors.
5. Once the all the bolts are in, tighten all bolts and make sure the seat still slides freely.

If you have any questions or experience issues, please contact your retail outlet first for help. However, the staff at PRP Seats is always happy to help at **1-800-317-6253**.

**Thank you! Ride safe!**

