



VIDEO AVAILABLE



Passenger side

Driver side



Designed to allow access to the OEM body mount bolts!

#### REQUIRED TOOLS

Socket set  
15mm box end wrench  
Tape - optional

#### KIT CONTAINS

Brackets (Left and Right)  
M10 Stainless hex bolt  
M10 Stainless flange nut  
M10 Stainless flat washer

#### QTY

1 ea  
8  
8  
8

#### NOTE:

It is assumed these brackets will be installed on an aftermarket bumper and the OEM bumper has already been removed and new bumper installed.

On one side of your rear bumper, remove the outer most bolts. These will be replaced with the hardware provided.

#### 1) INSTALL BRACKETS

The brackets must be installed on the correct side for proper fit. Please ensure you use the correct bracket on the correct side.



## INSTALLATION INSTRUCTIONS

**PART No.**

**FB21074**

### Jeep® TJ Wrangler Rear Bumper Tie-in Brackets

Loosely install the bracket to the rear crossmember using 2 M10 bolts, 2 washers and 2 serrated nuts.

Utilizing the factory hole locations in the frame of the jeep, insert a bolt and washer through the top hole of the bracket and into the frame.



Using a 15mm box end wrench, place the serrated nut in the closed end part of the wrench. **TIP:** Use a piece of tape to hold the nut in place.



Reach the nut into the frame through large opening in the bottom. Move the bolt around until you are able to thread the nut on the bolt. Once the tightening process has started, the serrated part of the nut will hold itself in place while you tighten. Repeat these steps for the lower hole.



Tighten all hardware for this side.

- 2) **REPEAT STEPS FOR THE OPPOSITE SIDE BRACKET**
- 3) **ENJOY YOUR NEW FISHBONE OFFROAD TIE-IN BRACKETS!**

