



INSTALLATION INSTRUCTIONS

PART No.

FB21099

**All Jeep® Wrangler Models
Door Hangers**



REQUIRED TOOLS

- Drill
- ¼" Drill Bit
- Ratchet
- 10mm Socket
- Spirit Level
- Tape Measure
- Marker

KIT CONTAINS

- Door Hanger Bracket
- 1/4" x 2" Lag Screw

QTY

- 2
- 4

2109900

1) ALIGNMENT

Locate desired studs and set your preferred height.

Hold the hangers up to desired location and balance it with a spirit level.



Using a marker, trace the hole locations.



2) MOUNTING

Drill pilot holes into the markings using a 1/8" drill bit.



Place the hanger up to the wall and secure it with two of the included screws, with a 10mm socket.



3) HANGING DOORS

Carefully remove your Jeep's doors and place them onto the hanger's foam padding, mirror facing out. Only one (1) door may fit on a single hanger at any time.

