



INSTALLATION INSTRUCTIONS

PART No.

FB21110

**Jeep® JL Wrangler
2018-Current Light Bracket - Cowl**



VIDEO AVAILABLE

REQUIRED TOOLS

T-40 Torx

KIT CONTAINS

Cowl Light Bracket (Left & Right)

QTY

1 EA

2111001

1) REMOVE OEM WINDSHIELD SUPPORT (COWL) BOLTS

If you already have aftermarket parts installed, remove them. Using a T40 Torx bit, remove the two top bolts and washers from the vehicle's windshield support/cowl.



Secure it by replacing the Torx bolts and washers.



Repeat steps 1&2 on the opposite side.



2) INSTALL LIGHT BRACKET

Place the bracket into the holes, foam side down, with the slotted flange pointing towards the center of the vehicle.



INSTALLATION INSTRUCTIONS

PART No.

FB21110

**Jeep® JL Wrangler
2018-Current Light Bracket - Cowl**

3) LIGHTING

Install your 40"-42" light bar or cube lights of choice following the manufactures instructions.



**ENJOY YOUR NEW FISHBONE OFFROAD COWL LIGHT
BRACKETS!**