



## **INSTALLATION INSTRUCTIONS**

**PART No.**

**FB21114**

General Tube Doors

**Tube Door Clamp Mirror**



### **REQUIRED TOOLS**

4mm Allen  
8mm Wrench

### **KIT CONTAINS**

Clamp Mirror (Top)  
Clamp Mirror (Bottom)  
Cap Screw

### **QTY**

1  
1  
2

#### 1) LOOSELY INSTALL

With two of the included screws, and a mirror top and bottom, loosely install the mirror so that it sits upright unassisted.



With an 8mm wrench, turn the hex nut behind the mirror clockwise so that the mirror doesn't rotate or fall.

#### 2) ADJUST TO PREFERENCE

Get inside your vehicle and move and twist the mirror into your desired position.



#### 4) ENJOY YOUR NEW FISHBONE OFFROAD CLAMP MIRROR!

#### 3) TIGHTEN THE BOLTS

With a 4mm Allen key, tighten down the 2 screws so that the mirror doesn't slide or rotate on the tube.

