

INSTALLATION INSTRUCTIONS

PART No.

FB23208F

**Jeep® JL Wrangler & JT Gladiator
JL & JT Front Steel Tube Fenders**



REQUIRED TOOLS

5mm Allen

KIT CONTAINS

Front Fender (Left & Right)
LED Turn Signal
Rubber Seal
M8 Button Head Bolt
M8 Flat Washer
M8 Serrated Nut

QTY

2
2
2
24
24
24

Note: These instructions will **NOT** cover how to remove factory fenders or inner fenders, and will **NOT** cover how to install inner fenders. Instructions on how to do so are available on www.FishboneOffroad.com, or www.FishboneOffroad.tv.

Jeep® JL Wrangler & JT Gladiator JL & JT Front Steel Tube Fenders

1) REMOVE

Begin by removing any inner and outer fenders your vehicle currently has installed.



2) PREPARE

The included rubber seals are driver and passenger side specific. Identify which side is which by the bolt hole indents in the rubber. Peel off the backing and carefully apply the seal to the vehicle side wall of each fender.



Install the included LED lights into their slots. Start by pulling the rubber seals off the lights, and firmly pushing them into the fender holes.



Pull the lights through and seat them into the seals so that the amber LED is furthest away from the vehicle, when right side up. Push the male connecting wires through the housing brackets/ and connect the **amber light to blue**, and the **white LED to red**, followed by the black and white wires to either ground connector.



Jeep® JL Wrangler & JT Gladiator JL & JT Front Steel Tube Fenders

3) INSTALL FRONT FENDERS

Hold the corresponding fender up to the vehicle and begin loosely securing it with 12 of the included M8 bolts, washers, and serrated nuts.

Connect the turn signal's power to the vehicle and begin tightening the bolts using a 5mm Allen key.

Remove the tape backing on the power converter and secure it to your vehicle as desired.



Repeat on the opposite side

4) ENJOY YOUR NEW FISHBONE OFFROAD JL & JT FRONT FENDERS

