



INSTALLATION INSTRUCTIONS

PART No.

FB23208R

**Jeep® JL Wrangler
JL Rear Steel Tube Fenders**



REQUIRED TOOLS

Drill
7/16" Drill Bit
5mm Allen
M8 Nutsert Tool

KIT CONTAINS

Rear Fender (Left & Right)
Rubber Seal
M8 Nutsert
M8 Button Head Bolt
M8 Flat Washer
M8 Serrated Nut

QTY

2
2
2
12
12
10

Note: These instructions will **NOT** cover how to remove factory fenders or inner fenders, and will **NOT** cover how to install inner fenders. Instructions on how to do so are available on www.FishboneOffroad.com, or www.FishboneOffroad.tv.

23208R00

Jeep® JL Wrangler JL Rear Steel Tube Fenders

1) REMOVE

Begin by removing any inner and outer fenders your vehicle currently has installed.

2) PREPARE

The included rubber seals are driver and passenger side specific. Identify which side is which by the bolt hole indents in the rubber. Peel off the backing and carefully apply the seal to the vehicle side wall of each fender.



In the body of the driver and passenger side rear fender panels, locate the hole shown below.



With a 7/16" drill bit, drill out the hole.



With an M8 Nutsert Tool, install a nutsert into each of the drilled holes.



Jeep® JL Wrangler JL Rear Steel Tube Fenders

3) INSTALL REAR FENDERS

Hold the corresponding fender up to the body and begin loosely securing it with 6 of the included M8 bolts, 6 washers, and 5 serrated nuts into the holes shown below and nutsert. The nutsert will not require a serrated nut.



With a 5mm Allen key, tighten down the bolts.

Repeat on the opposite side.

4) ENJOY YOUR NEW FISHBONE OFFROAD REAR JL FENDERS

