



# INSTALLATION INSTRUCTIONS

**PART No.**

**FB25101**

**Jeep® JL Wrangler  
Wheel Well Storage Bins**



## REQUIRED TOOLS

T50 Torx Bit  
5mm Allen

## KIT CONTAINS

Storage bins (Left and Right)  
Quick Install Knobs  
Washers  
Lock Washers (for soft-tops only)  
Button Head Bolts (for soft-tops only)

## QTY

1 EA  
4  
4  
2  
2

There are three (3) installation methods depending on your Jeep's current configuration. Please follow the instructions accordingly:

- A. Hard top with top on
- B. Hard top with top off
- C. Soft top\* – with top up or down

### A. FOR HARD TOP MODELS WITH TOP ON:

#### 1) **UNBOLT YOUR HARD TOP**

Inside your lift gate your hardtop will be bolted down by 6 bolts, with 3 on either side. Remove the innermost 2 on either side using a T50 Torx bit.



#### 2) **INSTALL STORAGE BINS**

Place the corresponding bin over the bolt holes.

Either using all of your OEM hardware, or the supplied four (4) knobs and washers, secure the storage bins in place.

2510100

## Jeep® JL Wrangler Wheel Well Storage Bins

**NOTE: Hard top Jeeps will not use the supplied lock washers and button head bolts.**



Secure the center bracket using 2 of the supplied Hardtop Knobs.



Secure the innermost bracket using a 5mm Allen with 2 of the supplied button head bolts, led by a flat washer and lock washer.

Repeat on the opposite side.

Resecure your soft-top.



**ENJOY YOUR NEW SET OF FISHBONE OFFROAD  
WHEEL WELL STORAGE BINS!**

### B. FOR HARD TOP MODELS WITH TOP OFF:

#### 1) **INSTALL STORAGE BINS**

With the top already off the Jeep, simply place the storage bins over the 2 innermost hardtop holes. Secure them in place using the supplied knobs and washers or your OEM hardware.

*\*To reinstall your hardtop, you must uninstall the storage bins first.*



### C. FOR SOFT TOP MODELS

#### 1) **INSTALL STORAGE BINS**

If your soft-top is up, remove the side windows and door surrounds.

With or without the soft top on (or down), place the bin over the 2 innermost hardtop holes.