



INSTALLATION INSTRUCTIONS

PART No.

FB25102

**Jeep® JK 2DR* Wrangler
Wheel Well Storage Bins**



VIDEO AVAILABLE



REQUIRED TOOLS

T-40 Torx

KIT CONTAINS

Storage bins (Left and Right)
Quick install knobs
Flat Washers
Hex Nut (for soft-tops only)

QTY

1 ea
4
8
4

There are three (3) installation methods depending on your Jeep's current configuration. Please follow the instructions accordingly:

- A. Hard top with top on
- B. Hard top with top off
- C. Soft top* – with top up or down

*** NOTE: Soft top Jeeps did not come from the factory with the hard top nut with clip. This configuration will need to use the supplied extra four (4) washers and four (4) nuts to complete installation.**

A. FOR HARD TOP MODELS WITH TOP ON:

1) **UNBOLT YOUR HARD TOP**

Begin by removing your Freedom top.

Remove the six (6) torx bolts (3 on each side) from either side of the hard top from inside the Jeep.

2) **INSTALL STORAGE BINS**

Lift the hard top just enough to slide a storage bin into place between the hard top and the Jeep body. Help from a friend is advised.



*** WILL NOT FIT 4DR MODELS**

2510200



Either using all of your OEM hardware, or the supplied four (4) knobs and washers, secure the storage bins in place. Resecure your hard top.

NOTE: Hard top Jeeps will not use the supplied nuts, and only four (4) of the washers.

B. FOR HARD TOP MODELS WITH TOP OFF:

1) INSTALL STORAGE BINS

With the top already off the Jeep, simply place the storage bins on top of the Jeep tub and align above the factory holes. Secure in place using the supplied knobs and washers and utilize the OEM hard top nut with clip.

C. FOR SOFT TOP MODELS

1) INSTALL STORAGE BINS

With or without the soft top on (or down), simply place the storage bins on top of the Jeep tub and align above the factory holes.

Using the supplied four (4) knobs, eight (8) washers, and four (4) nuts, securely fasten the storage bins in place.