



INSTALLATION INSTRUCTIONS

PART No.

FB25241

**Jeep® '18-Current JL Wrangler
Tub Rail Tie Downs**



REQUIRED TOOLS

Drill
7/16" Drill Bit
13MM Socket
Pencil

KIT CONTAINS

JL Tub Rail Tie Down (Left & Right)
Hardtop Knobs
5/16" Flat Washer
M8 Flash Washer
M8 Hex Nut

QTY

1 ea
4
4
2
2

1) REMOVE TUB ACCESSORIES

Prepare the installation area by removing any accessories from your tub rails, including our storage racks, bins, and any hardtop Torx bolts.



Depending on your preference or setup, the Tie Down will sit on top of any accessory, meaning the included knobs will secure it and anything extra.



2) REMOVE BACK SEAT

Remove your vehicle's back seats while taking care to not damage the fabric or your vehicle's paint job.

Store all removed hardware in a safe location in the event of reinstalling the seats.

3) TIE DOWN ORIENTATION

Determine the orientation you'd like for the Tie Downs, as they're driver and passenger side specific, but can be swapped by rotating them to face inboard or outboard.



4) DRILL

With a 7/16" drill bit, drill a hole, where you marked, through both your hardtop and tub rail by creating a pilot hole and working up to the required size.



5) INSTALL

Place all your desired accessories onto the rail with the Tie Down finally on top. With 2 of the included knobs and washers, secure the Tie to the tub rail. The two forward drilled holes will use the M8 Washers and M8 Hex nuts.



Repeat on the opposite side.

**6) ENJOY YOUR NEW FISHBONE OFFROAD TUB RAIL
TIE DOWNS!**

