

FISHBONE  
OFFROAD



## INSTALLATION INSTRUCTIONS

**PART No.**

**FB31264**

**2018-Current JL Wrangler  
Piranha Backside Plate**



### REQUIRED TOOLS

Ratchet  
4mm Allen  
12mm Socket  
13mm Socket  
T6 Torx Bit  
T25 Torx Bit

### KIT CONTAINS

M2 Button Head Bolt  
M6 Button Head Bolt  
M6 Nyloc Nut  
Delete Plug

### QTY

3  
4  
4  
2

## INSTALLATION INSTRUCTIONS

**PART No.**

**FB31264**

**2018-Current JL Wrangler  
Piranha Backside Plate**

### 1) **PREPARE**



Using a T-40 Torx wrench remove your spare tires retaining clip. Next remove the three lug nuts and remove the vehicle's spare tire.



Using a 13mm Socket remove the eight tire carrier bolts. Using a T-25 Torx bit remove the backup camera retaining plate, pull the camera free from the backside of the tire carrier.



Using a T-6 Torx bit unscrew the Backup camera from its mount. And remove the camera feed cable. Carefully place the camera aside.

Firmly grip and pull at the Spare Tire Bump Stops and remove them from the vehicle.

### 2) **ASSEMBLE AND INSTALL**

Using a T-6 Torx, carefully install your backup camera into the backside mount and reconnect its power.





## INSTALLATION INSTRUCTIONS

**PART No.**

**FB31264**

**2018-Current JL Wrangler  
Piranha Backside Plate**

NOTE: If you wish to paint the included Accent Plate, do so now.

Using a 4mm Allen Wrench and 12mm socket with the included button head bolts secure your license plate and/or Accent Plate to the backside.



With the camera facing down place the Backside to the tailgate and secure it to the tailgate using the eight 13mm bolts.

With the included 2 delete plugs, fill in the 2 holes Bump Stop holes that flank the bottom of the Backside.

**ENJOY YOUR FISHBONE OFFROAD BACKSIDE PLATE!**