



INSTALLATION INSTRUCTIONS

PART No.

FB33007R

**Jeep® JK Wrangler
Aluminum Inner Fenders – Rear Only**

FB33007R



REQUIRED



REQUIRED TOOLS

- Drill
- 5/32" Drill Bit
- Phillips Screwdriver

KIT CONTAINS

Phillips Pan Head Screw

QTY

10

- 1) REMOVE YOUR REAR OEM INNER FENDER/LINER**
If necessary, jack up your vehicle to give you more room to work. Ensure the vehicle is safely supported. Release the inner fender/liner by removing the push rivets from the Jeep fender well.

- 2) INSTALL YOUR REAR INNER FENDERS**
The below image shows which side to install the rear inner fenders on.



Flex and manipulate your new inner fender to work it into the fender well and around your tire. Work the inner fender until you have snapped it into place around all the Jeep fender edges and frame.

USE CAUTION WHEN DRILLING TO NOT HIT FUEL LINES OR HARNESSSES.

TIP! – Hold the inner fender in the highest possible point before drilling holes.

Using the holes in the inner fender as a guide, pre-drill the five (5) holes using a 5/32" drill bit.

Using the supplied screws, secure the rear inner fenders in place.

- 3) ENJOY YOUR FISHBONE OFFROAD INNER FENDERS!**

33007R00