



555 E Queen Creek Rd
Bldg A
Chandler, AZ 85286
WWW.DV8OFFROAD.COM

PRODUCT

INSTALLATION MANUAL

FAIRLEAD BLOCK OFF PLATE

UNIVERSAL

FBBO-01



TOOLS REQUIRED

- 19mm socket or wrench

SKILL LEVEL

- Novice
- 1 (you) to 2 persons

Little skill level required, you can easily install it by yourself however, additional help will be useful

TIME REQUIRED

- .5 Hours

Time to install this should only take about half of a hour.

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit — Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

• Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



NEED HELP?



855-680-9595

INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

HARDWARE INCLUDED

- (2) M12 Nylock Lock Nuts
- (2) M12 Flat Washer



STEP 1 | Begin by placing the block off plate onto the bumper where the winch fairlead would mount.



STEP 2 | Using the provided hardware (1 washer and 1 nuts per stud) and a 19mm, loosely mount hardware.



INSTALLATION MANUAL

STEP 3 | Center block off plate and then tighten hardware until plate is secure.



STEP 4 | Congratulations, you are done with the install of the DV8 Winch Block Off Plate.

