



INSTALLATION INSTRUCTIONS

PART No.

FB24077

**Jeep® TJ Wrangler
Tube Doors**



VIDEO AVAILABLE



REQUIRED TOOLS

13mm Wrench
4mm Allen wrench

KIT CONTAINS

Door (Left and Right)
Nyloc nut
Flat washer
Bolt
Strap
Door switch tab

QTY

1 ea
4
4
4
2
2

1) REMOVE EXISTING DOOR

Begin by removing your OEM or existing doors. Take care not to scratch the doors when removing and place them on a soft surface to protect the paint.

2) INSTALL TUBE DOORS

Insert the tube doors into the Jeep's body hinges and secure with supplied nyloc nuts using a 13mm wrench or socket. Do not overtighten as this may make the door hard to open.



2407700

INSTALLATION INSTRUCTIONS

PART No.

FB24077

**Jeep® TJ Wrangler
Tube Doors**

3) ATTACH DOOR CATCH STRAP

Install the door catch strap on the tube door. Close the tube door slightly to allow enough slack to install the strap on the hook inside the Jeep.



4) INSTALL DOOR SWITCH TAB

Using a 4mm Allen wrench and the supplied bolts and washers, attached the door switch tab to the door. **Be sure to push the tab as far back as you can in the slot, as shown in the picture below, to avoid putting too much force on the switch.** If the switch is not fully engaged when the door is closed, adjust the tab accordingly.



5) ADJUST LATCH MECHANISM

Fishbone Offroad's tube doors are designed with a rubber stopper that help eliminate rattling noises in the tube doors. Using a 4mm Allen wrench, adjust the latch in or out until the rubber stopper is touching the Jeep body snug when the door is closed.



6) ENJOY YOUR FISHBONE OFFROAD TUBE DOORS!

