

**WIRE IDENTIFICATION**

Green	=	Right Turn
Yellow	=	Left Turn
Brown	=	Tail / Park
White	=	Ground

1. Clean mating surfaces of the vehicle connector or 4-wire flat if needed.
2. Apply grease to the terminals.
3. Secure excess wire to the vehicle.
4. Plug completed assembly into the trailer and check the lighting system for proper operations with the engine running.

**TIPS:**

- Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.
- A heavy-duty flasher may be required to eliminate rapid flashing.
- Always unplug boat trailer connector before backing trailer into the water.

---

**IDENTIFICACIÓN DE CABLES**

Verde	=	Intermitente a la derecha
Amarillo	=	Intermitente a la izquierda
Café	=	Luz trasera de estacionamiento
Blanco	=	Puesta a tierra

1. Limpiar del conector del vehículo o de la extensión al remolque.
2. Aplicar grasa en los terminales.
3. Amarrar el cable excedente al vehículo.
4. Enchufar el conector de la extensión al remolque. Verificar el buen funcionamiento de las luces del remolque con el motor encendido.

**CONSEJOS:**

- Aplicar grasa periódicamente en el conector del remolque ayudará a evitar la corrosión
- Puede necesitar una luz intermitente para vehículos pesados para eliminar un parpadeo rápido.
- Desenchufe siempre el cable del remolque de barco antes de la puesta al agua.

Need Help? (English Only)  
1 800 835-0129

techsupport@hopkinsmfg.com

www.hopkinstowingsolutions.com