



SECURITY NUT KIT

CONTENTS

- (2) 1/4" 20 SPANNER NUT
- (4) 1/4" WASHERS
- (1) 1/4" HEX NUT BOLT

To Install – Remove Nylock nut and discard (remember to re-install the Delrin Bushing if it came off the light). Re-install light into aftermarket tabs, cradle, or adjustable clamps. Depending on thickness of tab or clamp, use 1 or 2 washers on each end. Start the Spanner Nut and tighten down with spanner bit.

BE SURE TO RE-CHECK TIGHTNESS PERIODICALLY

IS-40281 Rev2

1-855-760-LEDS (5337)

RIGIDINDUSTRIES.COM

Rigid Industries and Rigid are registered and/or unregistered trademarks of JST Performance, Inc. d/b/a Rigid Industries.



Rigid Industries® hereby renounces any and all warranties, guarantees, obligations, liabilities, express or implied, arising by law or otherwise, with respect to this security kit, and specifically disclaims any implied warranty of fitness for any purpose.

FOR MORE INFO

WWW.RIGIDINDUSTRIES.COM | 855.760.5337