

Installation Instructions

J2TR07R1BK
TRENCH BARRIER FOR
JK 2 DOOR 2007 -UP

-Thank you for purchasing a Dirtydog 4x4 trench barrier. Please read these instructions fully to familiarize yourself with the installation. This should only take about 10 minutes to install the first time

Slide the 4 straps through the slits on the front of the barrier as shown



This barrier is designed to be used only when the rear seat is removed. To install the barrier you must first remove the rear seat. Place the bottom bar in front of the seat bracket. Be sure to slide both sides of the strap uder the first loop of the floor bracket. Continue to slide the bottom strap through the next loop and tighten the strap down as shown. Do this step on both sides.





Install the two plastic hooks as shown under the tub lip so this grabs onto the tub. Postion these directly above the lower floor brackets.



Slide the top straps through the slot in the plastic hook and tighten. Do this on both sides. Your barrier is now installed.



Your barrier comes with a three year warranty against manufacturing defects.



Dirtydog 4x4 6-2045 Dundas St. E. Road Mississauga, ON L4X 1M2 1-855-704-0708 Question? Call or email orderdesk@dirtydog4x4.com