

CFE PRODUCTS
ALL MODELS
2007 to 2010 JK WRANGLER

P 2
rev P 65

Radio Installation

1. Carefully Lift up Dash Trim Cover using a small flat edge tool. (Do not pull away from the Dash. A wire will stay connected under the Cover) Lift up the back of the Dash Trim as shown in picture #1. Pull forward and rest the Cover as shown in picture #2.
2. Remove the Upper Two Screws on the Dash Panel as shown in picture #3.
3. Using a flat edge tool, remove the Lower Trim Panel as shown in picture #4.
4. Remove the two Lower Screws on the Dash Panel as shown in picture #5.

