

CFE PRODUCTS

ALL MODELS

2007 to 2010 JK WRANGLER

Radio Installation Continued

5. Starting at the top and working your way down, pull the Dash Panel forward releasing the clips that hold it in place. (The Panel will not be removed and the wires will not be disconnected) as shown in picture #6. Pull the Panel back far enough to remove the Factory Radio.
6. Using a 7mm socket remove the 4 screws and slide the Factory Radio out as shown in picture #7.
7. Remove the Factory Antenna Connector(s). You will only have the Yellow Connector if you have Factory Satellite Radio. Squeeze the side of the plug to release the Plug and remove as shown in picture #8. Repeat the same procedure for the White Plug (am/fm antenna).
8. Remove the Gray Factory Radio Plug by Squeezing the bottom to release the Plug as shown in picture #9.

