



WARNING:

This product can expose you to chemicals including vinyl chloride and lead, which is known to the state of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

CFE PRODUCTS
JK CUSTOM HEAVY DUTY BATTERY
TERMINALS



MODEL #JK- HDBT12
Jeep Wrangler JK / 2012 to 2018

rev 24

****Whenever working on your Battery, always Disconnect the Negative Terminal First (Black)****

1. Disconnect the Negative (Black) Battery Terminal then the Positive Battery Terminal.
2. Install the Battery Pads that are included in the Kit.
3. Take the Brass Buss Bars included in the Kit and install them on the Unused Stud on the Battery Terminals as shown by the 2 Yellow Arrows and also picture 1A. Secure them with the Stainless Steel Flange Nuts.
3. Reattach the Positive (Red) Battery Terminal first, then Negative (Black) Battery Terminal.

The picture below shows the connection of an optional accessory.

Winch cables should be installed under the Stainless Steel Flange Nuts. (shown by the Black and Red Cables pictured below)

Other Accessories can be installed under the 2 remaining Flange Head Machine Screws.

