



**New and Improved, Now
with Mag Safe Mount
available!**

CFE PRODUCTS

MODEL # JK-PMM 0710

Jeep JK Wrangler Magnetic or Grab Handle Phone Mount
2007 to 2010 JK



WARNING:

This product can expose you to chemicals including vinyl chloride and lead, which is known to the state of California to cause cancer and birth defects or other

reproductive harm. For more information www.P65Warnings.ca.gov

Part # 14133-1202

1. Using a pry stick or small flat edge screw driver, carefully pry off the plastic trim cap of the left side grab handle as shown in picture #2. The cap will slide off to the left.
2. Clean out the inside of the hole of the grab handle to allow the supplied Rubber Insert to fit securely. Insert the Rubber Insert as shown in picture #3.
3. Ensure that the Rubber Insert is pushed in flush with the grab handle as shown in picture #4. It is very important that the Rubber Bushing is flush with the Grab Handle as shown by the Yellow Arrow in picture #4. No Rubber should stick up. Install Metal Washer as shown.
4. Remove Paper Backing from the Pad on the Phone Mount as shown by Yellow Arrow in picture #5.
5. Install the Phone Mount using the Black Flat Washer and Black Plastic Acorn Nut as shown in picture #5. Make sure to push the metal plate firmly against the grab handle.
6. Remove Paper Backing from the Pad on the Phone Mount as shown by Yellow Arrow in picture #5.
7. Tighten the Acorn Nut only hand tight to start. Then use a small open end wrench to slowly turn 1/4 turn at a time until the mount is secure. *Do Not Use a Ratchet Wrench.*
8. For Magnetic Mount, Install the metal ring either between your phone & phone case, or on the outside of the phone case [outside the case for the strongest hold]



Questions or Comments ? call CFE PRODUCTS @

610 358 1886 / ASK FOR BOB