



MOUNTAIN OFF ROAD ENTERPRISES, LLC.
P.O. BOX 690 DELTA COLORADO 81416
(877)JEEP-A2Z or (877)533-7229
(888)-698-5337 FAX
E-mail: info@mountainoffroad.com
www.mountainoffroad.com

INSTALLATION INSTRUCTIONS for JKRS07



HARDWARE KIT:

- 1- JK Roller Shade
- 2- Roll Bar Half Clamps
- 2-1/4" x 1/2 Carriage Bolt
- 2-Cam Clamps
- 2-Threaded Dowels for Cam Clamps
- 2- 1/4" Top Locks
- 2- 1/4" flat washers
- 2- Z clips
- 2- #10 x 1" self drilling screws
- 6- Bungee Cords

Please read and understand all instructions before beginning the installation of the JK Roller Shade. Please read the terms and policies on the back of these instructions.

The **JKRS07** JK Roller Shade is designed to fit the following Jeep® vehicles: 2007-2017 4 door hard and soft top vehicles along with 2 door hard top JK Wranglers.

Note: You will only use the half clamps on the 2 door hard top and 4 door soft top Wranglers. With a soft top you will have to remove the Roller Shade with the half clamps each time you want to put your soft top up or down.

4 door hard top models mount directly to the roll bar. The hard top must be removed for installation purposes on both models.

2 Door and 4 Door Soft Top Mount:

STEP 1: Clamp the half clamp with the carriage bolt inserted into stainless steel half clamp around the zipped fabric. Position clamps so that the top of the Roller Shade triangle box is at or below the top of the roll bar. This will allow the hard top to be reinstalled without inference. (see photo 1)

STEP 2: Mount the JK Roller Shade ends to carriage bolt using a flat washer and 1/4" nut and tighten.

STEP 3: Roll out fabric and hook into the 2 D rings at the windshield, Attach the bungee cords through the brass eyelets and around the roll bar. You will need to adjust the length on the bungee cords for a tight fit.

4 Door Hard Top Mount:

1: After you remove the hard top, unzip the left and right roll bar covers exposing the two bolts towards the top of the roll bar.

2: Remove the bolts completely

3: Install the factory bolts through the slots in the legs of the Roller Shade.

4: Mount the Roller Shade and bolts back into the factory location and tighten. (see photo 2)

5: Roll the fabric out until it is at the center cross member of the roll bar. (between the front and back seats.)

6: Center the fabric left to right. Using the hooks of the stainless steel bar stitched into the fabric as a guide, drill and mount the stainless steel Z clips to the top of the cross member of the roll bar. (see photo 3) These clips can be used as an intermediate attachment point for the roller shade.

7: Roll out fabric and hook into the 2 D rings at the windshield. Attach the bungee cords through the brass eyelets and around the roll bar. You will need to adjust the length on the bungee cords for a tight fit.

Photo1 2 Door Hard Top & 4 Door Soft Top



Photo 2 4 Door Hard Top Mount Option Only



Half Clamp Assembly



Photo 3 Z Clip Mount for 4 doors



Enjoy your sunny day in the shade!!



TERMS-POLICIES:

FIT and **TOLERANCES:** M.O.R.E.™ parts are the results of countless hours of research, testing, fitting and refining. Jeep® frames have a wide tolerance on bolt hole centers from frame to frame. This is why M.O.R.E.™ has installed “slots” in which to mount them. In addition to the factory tolerances, most people install other than factory equipment such as suspension lift kits, skid plates, different transfer cases etc. M.O.R.E.™ has done the best job we can to insure that our parts fit with all of the possibilities. However, you may find it necessary to grind, elongate, bend, or force these parts to fit on your rig. Please use common sense when installing these parts and let us know how we can improve them.

DAMAGE CLAIMS: All orders are carefully packed, however, mishandling by the carrier can result in damage. The carrier has the responsibility for the shipment from the time it leaves our warehouse until it is delivered to you. All claims for lost or damaged goods should be reported to the carrier, not to **M.O.R.E.™** LLC.

RETURNS: No returns will be accepted without prior permission from **M.O.R.E.™** LLC. After you receive a Return Goods Authorization (RGA) number, merchandise must be returned prepaid and insured. A claim must be made within 30 days from receipt of merchandise. The original invoice or a copy with the RGA number written on must accompany all returns. A 20% restocking fee will be charged on all parts returned for credit or refund unless merchandise is proven to be defective or was shipped wrong by **M.O.R.E.™** LLC. No merchandise will be issued credit or refund if it has been installed, modified, used in any way or is in unsalable condition.

WARRANTY: All merchandise is warranted to be free from defects in materials and workmanship prior to installation. Any alteration or improper use will void this warranty. Because all parts we sell are intended for use in heavy-duty applications it is not possible to warrantee or guarantee the performance of any items. **M.O.R.E.™** LLC. products and the products manufactured by others, which we sell may be subject to an infinite variety of conditions due to the manner in which they are used, serviced and/or installed. Purchasers and users of such products rely upon their own judgment as to the suitable use selection, service and installation of such products.

PRODUCT DISCLAIMER: Modification of your vehicle to enhance performance with parts sold by **M.O.R.E.™** LLC. may create a dangerous condition which could cause serious bodily injury, and the buyer hereby expressly assumes all risks associated with any such modifications. All parts sold by **M.O.R.E.™** LLC. are for racing or off road use only. Mountain Off Road Enterprises LLC. will not accept responsibility for personal injury or property damage arising from the failure of any parts manufactured or sold by **M.O.R.E.™** LLC.

Specifications are subject to change without notice.

Jeep®, AMC®, CJ®, YJ®, TJ®, LJ®, JK®, Wrangler®, are registered trademarks of DaimlerChrysler. **M.O.R.E.™** is not affiliated with DaimlerChrysler.

M.O.R.E.™, BombProof™, S.R.S.™, SlipLoc™, DoubleJointed™, RockProof™, are trademarks used by **Mountain Off Road Enterprises, LLC.** These instructions and the M.O.R.E.™ logo are copyright©, 1999-2009.