

## JL Camera/3<sup>rd</sup> brake light mount

2 – Lug Adapters

2 – ¼” Allen Bolts

3 - #2 Bolts and nuts

1 – Relocation Bracket

## 3<sup>rd</sup> brake light removal

1. Remove spare tire and the spare tire carrier.
2. Remove the 7 bolts from the front upper brake light mount. Remove the back of the mount from the front.
3. Remove the 3<sup>rd</sup> brake light wiring and unplug from the harness.
4. Remove the 4 bolts holding the brake light mount upright to the tire carrier and remove the mount.
5. Remove the 3<sup>rd</sup> brake light. There are 3 bolts holding it on the mount.

## Camera removal

1. Remove the spare tire mount from the jeep door, there are 8 bolts attaching it.
2. Unplug the camera from the factory harness
3. Remove the studs/camera assembly from the mount. The studs will push back through the tire carrier. They are attached the camera mount. They are in rubber press fit so they can be tight coming out.
4. Once out you can see the camera mount. Unscrew the 3 screws holding the camera to the camera mount and remove the camera.

## Installation

1. Attach the camera to the mount using the supplied #2 bolts and nuts
2. Attach the 3<sup>rd</sup> brake light using the factory hardware.
3. Replace the factory spare tire carrier if reusing it.
4. Replace spare tire, using the supplied lug adapters in the top 2 locations.
5. Attach the Iron Cross Relocation Bracket using the supplied ¼” Allen bolts.
6. Reattach the wiring for the camera and/or 3<sup>rd</sup> brake light at this time.