



Installation Instructions  
for  
Front Skid Plate, JP-5000 and JP-5009  
for  
2007-2018 Jeep® JK Wrangler

Thank you for purchasing your new Skid Row Offroad front skid plate. It is designed to give you peace of mind while traversing even the toughest trails.

Your skid plate package should come complete with the following parts:

- |  |                               |
|--|-------------------------------|
| 1. (1) Front Skid Plate                | 5. (2) 3/8 Small Flat Washers |
| 2. (2) 3/8-16 x 1" Carriage Head Bolts | 6. (4) 3/8 Large Flat Washers |
| 3. (2) 3/8-16 x 1" Hex Head Bolts      | 7. (4) 3/8 Lock Washers       |
| 4. (4) 3/8-16 Hex Nuts                 |                               |

**Step 1:** Remove the factory plastic front "skid plate".

**Step 2:** Lift the front skid plate into place and simply bolt it to the frame as shown in the photo below. Use the two hex head bolts at the top and the two carriage head bolts at the bottom of the skid plate. Place the 2 small flat washers under the heads of the hex bolts to prevent damage to the finish. The 4 large flat washers are used under the nuts and lock washers.

**Note:** Not all of the holes at the bottom edge of the skid plate are used. The hole pattern on your front crossmember varies depending on the model year of your Jeep.

**Step 5:** Tighten all four bolts and you're ready to hit the trail!



We hope you enjoy your new Skid Row Offroad Front skid plate!

Sincerely,

**The Staff at**

**SFK Manufacturing, LLC**  
PO Box 306, Shermans Dale, PA 17090  
Phone 717-701-8315  
Fax 717-701-8316

[www.SkidRowOffroad.com](http://www.SkidRowOffroad.com)