



Installation Instructions for Foot Pegs for Jeep® JL, Front Doors

Thank you for purchasing your new Skid Row Offroad Foot Pegs.
Your Foot Peg package should come complete with the following parts:

1. (1) Driver's Side Foot Peg (shown on left)
2. (1) Passenger Side Foot Peg (shown on right)
3. (2) Hairpin Cotter Pins
4. (2) Vinyl Caps



Step 1: Slip the vinyl caps onto the tab on each of the foot pegs.

Step 2: After removing your Jeep's doors, place each foot peg into the lower hinge on each side, put one of the hairpin cotter pins through the hole below the hinge, and you're ready to enjoy driving doorless with a comfortable place to put your foot!

We hope you enjoy your new Foot Pegs!
Sincerely,

The Staff at SFK Manufacturing, LLC

SFK Manufacturing, LLC
PO Box 306, Shermans Dale, PA 17090
717-701-8315
Fax 717-701-8316

www.SkidRowOffroad.com