

JP54-024

# OFFROAD JACK CARRIER

## INSTALLATION INSTRUCTIONS



*\*Easily mounts to the Heavy-Duty TJ hinges, sold separately.*

*\*Maximum compatible spare tire size with the carrier is 33".*

### STEP 1

Remove the spare tire.

### STEP 2

Hold the backer clip behind the middle 1" hole in the upper hinge (most easily accessed from behind the hinge with the tailgate open).

### STEP 3

Insert the bolt through the right side of the upper bracket and thread into the backer clip.

### STEP 4

Repeat Step 3 with the left side of the upper bracket.

### STEP 5

Use the bolts and nuts to attach the lower tray to the lower hinge in the 3/8" holes.

### STEP 6

Install the carriage bolt into the upper bracket. Put the washer onto the bolt and tighten the jam nut to hold the bolt in place.

### Tools Needed

- 3/4" Wrench
- 1/2" Wrench
- 1/2" Socket

**MORryde**

**HEAVY. DUTY. ADVENTURE.**

[www.MORryde.com](http://www.MORryde.com) • 574.293.1581

JP54-024

# OFFROAD JACK CARRIER



## INSTALLATION INSTRUCTIONS

### STEP 7

Place the base of the jack into the lower tray. With the base resting in the tray, one of the holes in the bar of the jack should fit over the carriage bolt.

### STEP 8

The upper bracket and the lower tray can be adjusted vertically to get a hole to align with the carriage bolt. The upper bracket and lower tray can also be adjusted side to side to get the jack to sit vertically.

### STEP 9

Once the bracket and tray are adjusted, tighten the bolts to secure them to the hinges.

### STEP 10

Use the 1/2" lock nut to secure the bar of the jack to the upper bracket (compatible with the Wrangler's lug nut wrench).

### STEP 11

It is recommended to use a handle keeper (not included) on the jack to secure the handle to the bar during transport.

**MORryde**

**HEAVY. DUTY. ADVENTURE.**

[www.MORryde.com](http://www.MORryde.com) • 574.293.1581