

INSTALLATION INSTRUCTIONS

PART No.

70011, 70012 Jeep® JL Wrangler Door Hinge Liners







REQUIRED TOOLS

Flathead screwdriver/chisel Hammer

KIT CONTAINS	QTY
Hinge liner (70011 - 2DR version)	4
Hinge liner (70012 - 4DR version)	8
Removal tool	1

1) REMOVE YOUR DOOR

Roll the window down on the door you will remove. Disconnect the electrical connector, door strap, and door limiting stop.

Lift up and remove your door. Be sure to store it on a soft blanket or cardboard to prevent paint damage.

2) REMOVE THE OEM HINGE LINERS

The OEM hinge liners on the JL are swaged on both sides of the hinge. Using the flathead or chisel, very carefully knock the top lip of the liner inward to clear the edge of the hinge.



Tap all sides of the OEM liner until the top is completely clear of the OEM hinge.



Using the included tool and a hammer, tap the OEM liner out of the hinge. Take care in controlling your swings to avoid damaging your paint.

Repeat this step on the second hinge.

7001100



INSTALLATION INSTRUCTIONS

PART No.

70011, 70012 Jeep® JL Wrangler Door Hinge Liners

Ensure the tool can freely slide in and out of the hinges. This will make for easier insertion of the new liners.



3) INSTALL NEW LINERS

Place the new liners into the door hinges. These should press in gently with your fingers. If more force is needed, use the tool again to reem the hole to remove any remaining corrosion or debris.



 REINSTALL YOUR DOOR AND REPEAT FOR ALL REMAINING DOORS.