

INSTALLATION INSTRUCTIONS

PART No.

80715

Mechanical Hood Catch Kit for Jeep® JL Wrangler









INSTALLATION INSTRUCTIONS

PART No.

80715

Mechanical Hood Catch Kit for Jeep® JL Wrangler

| REQUIRED TOOLS | KIT CONTAINS | QTY |
|----------------|--------------------------------------|-----|
| 10mm SOCKET | STAINLESS HOOD LATCH | 2 |
| 13mm SOCKET | STAINLESS HOOD CATCH | 2 |
| 4mm HEX KEY | RUBBER GASKET FOR LATCH | 2 |
| 7mm HEX KEY | RUBBER GASKET FOR CATCH | 2 |
| THREADLOCKER | STAINLESS HEX BOLT | 4 |
| | STAINLESS LOCKNUT AND WASHER (Latch) | 4 |
| | STAINLESS LOCKNUT AND WASHER (Catch) | 2 |

1) Remove Your Old Hood Catches

Lift the hood and remove your old hood catches from the hood and fender of the driver's side of the Jeep.

2) Install Hood Catch on Fender

Align the threaded bolt and rubber gasket with the holes in the fender and set the new hood catch in place. Install an 8mm stainless washer and 8mm locknut. Tighten using a 13mm wrench. Ensure to keep the catch and gasket even for a clean look.



3) Install Hood Catch on Hood

Line up hood catch latch with rubber gasket. Insert the two 6mm hex bolts through the latch and hood. Install a 6mm stainless washer and 6mm locknut on each hex bolt. Using the 4mm hex key and a 10mm socket, tighten the bolts. Ensure the rubber gasket is positioned properly before



tightening.



4) Apply Threadlocker *

Using an 7mm hex wrench while pulling slightly on the body of the hood catch remove the captive adjustment bolt. If you do not pull back slightly on the catch, you will begin to unscrew the adjustment bolt and it may bind. Simply screw it back in and try again.



INSTALLATION INSTRUCTIONS

PART No.

80715

Mechanical Hood Catch Kit for Jeep® JL Wrangler



Completely unscrew the adjustment bolt, removing the top portion of the latch. Apply threadlocker to the threads.

5) Adjust Latch

Reinstall the top portion of the latch, then close and latch the hood. If the latch will not close, loosen the adjustment bolt. Once the latch is closed, press down on the hood and check for movement. Tighten the adjustment bolt until there is no movement when you apply pressure to the hood.



6) Repeat steps on passenger's side