



INSTALLATION INSTRUCTIONS

PART No.

KIT CONTAINS

Door Bushing Removal Tool

Hinge Liner (2DR kit 70001)

Hinge Liner (4DR kit 70002)

70001, 70002 Jeep® JK Wrangler Door Hinge Liners - 2DR and 4DR





QTY

1

4

8

REQUIRED TOOLS

Hammer Torx T-50

OPTIONAL

Sandpaper Lubricant/Penetrating Fluid

NOTE:

THESE LINERS ARE ONLY DESIGNED FOR OE DOOR HINGES. DO NOT ATTEMPT TO INSTALL IN AFTERMARKET HINGES.

REMOVE YOUR DOORS

Roll down all your windows. Using a Torx T-50 bit, remove the nuts located on the base of each of your door hinges.

Disconnect the electrical connectors and door catch strap from each door. For 4DR applications, you will need to move your front seats forward to remove the access panel that covers the connector and door strap connecting points. Remove this cover and disconnect the strap and electrical connectors.



7000100



INSTALLATION INSTRUCTIONS

PART No.

Jeep® JK Wrangler Door Hinge Liners – 2DR and 4DR

Carefully lift each door from the hinges and safely set to the side to avoid damage or scratches.



REMOVE OE LINERS

You may want to use a piece of cardboard or a shop rag to protect the side of your Jeep from errant hammer swings. If the OE door bushings are stubborn, you may want to soak them in a penetrating lubricant.

Using the included removal tool, insert the tip of the tool into the bottom of the door hinge. The OE hinges have a flange on top, so they must be removed from the bottom up.



Using a hammer, tap the removal tool until the OE liner has been completely removed. You may need to tap the tool back though the hinge to remove it depending on how much corrosion has built up in the OE hinge. Repeat for all door hinges.

3) INSTALL YOUR KENTROL HINGE LINERS

If necessary, lightly sand the inside of the hinge until it is smooth. Slide the hinge liners into the hinges. Do not use a hammer, as it may break the liners. If necessary, use a small amount of grease.



If the liners do not install easily, please check that you have OE hinges. Some aftermarket hinges look very similar to OE hinges.

4) REINSTALL YOUR DOORS

Insert your doors back into your hinges. Reconnect the electrical connectors and door straps. For 4DR applications, replace the access panels in the rear.

5) ENJOY YOUR NEW KENTROL HINGE LINERS!