

METAL BUMPER PUSH BAR

2018+ JEEP JL/JT

LBJL-13



TOOLS REQUIRED

- T45 Torx Tool

SKILL LEVEL

- Novice/Intermediate

- 1 (you)

Little skill level required, you can easily install it by yourself.

TIME REQUIRED

- 1 Hour

Time to install this should only take about one Hour.

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit — Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.

Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

• Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover




INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

HARDWARE INCLUDED



STEP 1 | Using a T45 torx tool, remove the factory (4) bumper bolts.



INSTALLATION MANUAL

STEP 2 | Place the push bar onto the bumper, aligning the mounting holes over the bumper holes.

Center the push bar with the bumper.

Tech tip: It is easier to mount your chosen lights before mounting the push bar to the bumper.



STEP 3 | Using a T45 torx tool and the factory bumper hardware, secure the DV8 push bar to your factory bumper.



STEP 4 | Secure any loose wiring using the zip tie cut outs in-between each light mount slots.

Congratulation, installation of the DV8 Metal Bumper Push Bar.

