



Dash Tray w/ Phone/GPS Mount 2011-2018 Jeep JK Wrangler P/N: RT27059

Kit Contents

- (1) Phone/GPS Upright
- (1) Phone/GPS Pivot Ass'y
- (1) Phone/GPS Mount
- (1) Dash Tray Insert
- (4) Short Phone/GPS Arms
- (4) Long Phone/GPS Arms
- (1) Washer

Required Tools

- 1/4" Ratchet
- 8mm Socket



Read all instructions carefully prior to starting installation.

1. Remove the factory rubber dash tray insert (See Figure 1).
2. Using an 8mm socket, remove the screw under the dash tray insert.
3. Install the Phone/GPS Upright to the dashboard using the included Washer and factory screw (See Figure 2). Tighten the screw securely with the 8mm socket.
4. Install the Phone/GPS Pivot Assembly onto the back of the Phone/GPS Mount.
5. Remove the nut from the Phone/GPS Pivot Assembly and install it onto the Phone/GPS Upright. Snap the socket on the Phone/GPS Pivot Assembly onto the ball of the Phone/GPS Mount (See Figure 3). Tighten the nut.
6. Slide the appropriate Phone/GPS Arms onto the Phone/GPS Mount (See Figure 4).
7. Install the Dash Tray Insert.
8. Test fit your device. Make any adjustments necessary.



While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co., Inc. cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure.