



Roll Bar Pad and Cover Kit

Tools needed for Installation:

T40 and T50 Torx bits

3/8" Ratchet

Razor blade

#2 Phillips Screwdriver

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE ATTEMPTING INSTALLATION

- 1) If you have a hard top on your vehicle, remove it. Refer to the factory instructions. If you have a soft top on your vehicle, remove it from the front retainer on the windshield frame. Refer to the factory instructions.
- 2) Remove the bottom bolt on the windshield retaining brackets at the bottom of the windshield. The windshield retaining bracket is the bracket that bolts the windshield frame to the dashboard.
- 3) Wranglers only: Remove existing roll bar pad from main bar to expose head of bolt holding the windshield brace to the main roll bar. Remove the bolt. Gently lower the windshield frame onto the front hood.
- 4) Remove the factory seat belt mounting bolt from the roll bar.
- 5) Install the new cover. Start with the main bar, then proceed to the two bottom lengths below the rear braces, then finish with the rear braces. Start the zippers and then twist the pad so the zipper is straight, then continue to zip the pad up completely.
- 6) Wranglers only: Remove the factory front brace covers by sliding them off of the rear portion of the front brace. Install new Rampage Products front brace covers.
- 7) CJs only: Use your finger and feel for the bolt hole in the seat belt bolt was bolted into and cut an X with the razor blade. Insert the bolt through this cut and start turning the bolt by hand, then tighten with the ratchet. Repeat on the opposite side.

Wranglers only: Use your finger and feel for the bolt hole in the seat belt bolt was bolted into and cut an X with the razor blade. Tilt your windshield back up until the windshield brace meets the roll bar. Unzip the roll bar padding enough to insert the bolt under the roll bar pad bolting the windshield brace to the main roll bar, then insert the seat belt bolt through the cut and start turning the bolt by hand, then tighten with the ratchet. Repeat on opposite side.
- 8) Reinstall your soft top or hard top as per the factory instructions.

NOTE: Roll bar pad kits for 1991 and older Jeeps do not come with the windshield brace pads. The kit is designed for installation on CJs that do not have these braces. If you have a 1987 - 1991 Wrangler, please purchase part number 769115 from your retailer to have the pads you need to finish the kit.

Important Care Instructions:

Convertible tops and accessories require special care if you want to get the maximum usage and enjoyment from them. The following recommendations, if followed carefully, can extend the life of your top or accessory.

Hand wash using a mild non-detergent soap such as ivory. Use a non-abrasive cloth or sponge. Rinse thoroughly.

Do not wash in direct sunlight and avoid automatic car washes

When your top is clean, we recommend using "Ragg Topp" or "303 Protectant" on both the vinyl top and windows. This product contains a sunscreen that helps protect from the sun's damaging rays. Stay away from products containing alcohol, as it will cause the fabric and windows to lose their elasticity, thus reducing the life of your top or accessory. If you are unable to locate "RaggTopp" Please call 1-800-377-4700 for a distributor near you. For "303 Protectant", please call 1-800-223-4303 for a distributor near you.

Direct sunlight and heat are the biggest enemies of the windows. Park in the shade whenever possible. If you must park in the sunlight, rotate the direction that you park every few days so all windows get even exposure.

Our tops are designed so that you may roll up and/or store the rear curtain and side curtains. To prevent scratching of the windows, be sure that windows are completely clean and free of dust particles. Even a little dirt will badly scratch the windows. You may want to use a soft cloth when rolling up or storing your windows. Heat may build up on rolled up windows, so be sure to unroll them frequently. If you roll up the windows at the beginning of summer and leave them, they may be ruined by fall.

Do not open or roll up windows at temperatures below 45 degrees F this could cause them to crack or break.

Zipper Care.

DO NOT use pliers or other tools to pull on zippers. If the zipper requires more force than pulling with your fingers something is most likely out of alignment or improperly installed. Be sure the top is up to a temperature of 70 deg., and that the components are installed correctly and in the correct sequence to ensure protection of the zipper.

Zippers require periodic cleaning and lubrication to ensure longevity and ease of use. Clean by wiping with a towel soaked in soap and water, DO NOT USE HARSH CHEMICALS. Zipper lubricants are available at sporting goods stores and online for wetsuits. An occasional use will keep the zipper slides operating as new.

Warranty Information

Rampage products, Inc. warrants to the original purchaser of any top it manufactures, that the top will be free of defects in material or workmanship for a period of 2 year from date of purchase. Such obligations under this warranty shall be limited to the repair or replacement, at Rampage products discretion, of any assembly or parts which, upon examination by Rampage products, Inc. proves to be defective. All defective items must be returned with proof of purchase to Rampage products, Inc., freight prepaid. This warranty does not cover damage resulting from abuse, misuse, alteration, accident or damage in transit. Rampage products obligations under this warranty are limited to the aforementioned repair or replacement of warranty defects for which the return authorization has been received during the warranty period, and Rampage products, Inc. shall not be liable for any incidental or consequential damages arising from breach of this or any implied warranty.

Rampage Products Buford, GA
Phone:800-328-2409
www.rampageproducts.net