

Sto-R-Doors Instructions

- Thank you for your purchase.
- No assembly is required for the unit.
- **MOUNTING:** Find a suitable and safe area to mount the unit (for 2 doors) or two units (for 4 doors).
- Locate a **SOLID** surface such as a stud or solid wall. This is **essential** for a safe and secure mount.
- **Find the center of a stud**

See back for assistance

Solid Wall

Dry Wall: with or without anchors is NOT a solid or sufficient mounting structure

Wood: wood screws provided

Concrete: anchors will be required

- Determine desired height from floor to allow doors to hang freely.
- Two (2) 2.5" Self-tapping 1/4" hex head mounting screws with washer are provided
 - a. Mounted properly, this will provide sufficient retention for a load not to exceed 150lbs/67kgs. (two doors). Add a third wood screw if desired.
 - b. **Highly Driven Products is not responsible for any damage to persons, doors, walls, or any property as a result of poorly or improperly mounted door racks.**

HDP.SRD6.1.20

Thank you....see us on www.highlydrivenproducts.com for more products!!!!

