

Tools Required:

Alcohol Clean Rag

Hardware / Parts List:

8 Stainless Door Hinge Accents

2 Stainless Hood Hinge Accents

<u>Step 1</u>

Read and understand all instructions before attempting the install of this grille. Be sure that the package of hardware matches the hardware list as listed above. Next, test fit the T-REX grille to the vehicles factory openings. You are now ready for the install:

Step 2

Clean the area of the door and hood hinges using alcohol and a clean rag. Test fit the accent to the vehicle. Unpeel the backing of the accent piece. Making sure the accent is straight; apply to the hinge. With the accent piece straight; apply pressure to the accent till adhesion has been accomplished. Repeat on all hinges.

Thank you for purchasing your T-Rex billet grille. 03/11/13