

CRAWLTEK

REVOLUTION

491 W. GARFIELD AVE., COLDWATER, MI 49036 • 517.278.1039
CRAWLTEKREVOLUTION.COM • E-MAIL: TECH-CRAWLTEK@RIDEFOX.COM

INSTALLATION INSTRUCTIONS

PYRO FRONT BUMPER

TJ10101/TJ10111/TJ10121/TJ10131 - STUBBY
TJ10201/TJ10211/TJ10221/TJ10231 - MIDWIDTH

**FOR USE WITH ALL
CJ/YJ/TJ MODELS FROM 1976-2005**



CrawlTek YouTube

PLEASE READ THROUGH INSTRUCTIONS BEFORE INSTALLING

2023-10-17

WHAT'S IN THE BOX?

PLEASE VERIFY KIT CONTENTS BEFORE BEGINNING INSTALLATION

PART #	Qty	DESCRIPTION
06086	1	FRONT BUMPER - TJ PYRO STUBBY (TJ10101 ONLY)
06152	1	FRONT BUMPER - TJ PYRO STUBBY - BULLBAR (TJ10111 ONLY)
06153	1	FRONT BUMPER - TJ PYRO STUBBY - FLAT TOP STINGER (TJ10121 ONLY)
06154	1	FRONT BUMPER - TJ PYRO STUBBY - STINGER (TJ10131 ONLY)
06087	1	FRONT BUMPER - TJ PYRO MIDWIDTH (TJ10201 ONLY)
06155	1	FRONT BUMPER - TJ PYRO MIDWIDTH - BULLBAR (TJ10211 ONLY)
06156	1	FRONT BUMPER - TJ PYRO MIDWIDTH - FLAT TOP STINGER (TJ10221 ONLY)
06157	1	FRONT BUMPER - TJ PYRO MIDWIDTH - STINGER (TJ10231 ONLY)
06176	1	CRAWLTEK SS LOGO 2"
C0041	1	LOGO RIVETS
164	1	MOUNTING SPACERS
CWL30010	1	DECAL: CRAWLTEK GEARSHIFT 3.5" X 3.5"
CWL30020	1	DECAL: CRAWLTEK EYES 6" X 2"
CWL30030	1	DECAL: CRAWLTEK JAX 3.75" X 2.8"
C0031	1	BOLT PACK
	6	1/2"-13 X 1-1/2" HEX CAP SCREW
	12	1/2" SAE FLAT WASHER
	6	1/2"-13 PREVAILING TORQUE NUT

TOOLS REQUIRED

SAFETY GLASSES

1/2" SOCKET OR WRENCH

T55 TORX SOCKET

10MM SOCKET OR WRENCH

RATCHET

FACTORY BUMPER REMOVAL

STEP 1:

IF YOUR VEHICLE IS EQUIPPED WITH FACTORY FOG LIGHTS DISCONNECT WIRING.



STEP 2:

REMOVE (4) T-35 BOLTS FROM THE TOP OF THE BUMPER AND (2) T-35 BOLTS FROM THE BOTTOM OF THE BUMPER, REMOVE BUMPER

STEP 3:

REMOVE (4) BOLTS HOLDING THE SWAY BAR ON (KEEP FOR REINSTALLATION).

ASSEMBLING THE JEEP PYRO FRONT BUMPER

STEP 4:

INSTALL WINCH ON TO BUMPER ASSEMBLY WITH BOLTS SUPPLIED FROM WINCH MFG.

INSTALLATION OF THE PYRO FRONT BUMPER

STEP 5:

SET BUMPER ONTO FRAME RAILS.

STEP 6:

SLIDE SWAY BAR OVER WINCH PLATE.

STEP 7:

INSTALL NEW 1/2"-13 BOLTS AND WASHERS SUPPLIED, INSTALL OEM SWAY BAR BOLTS. IF YOU ARE INSTALLING YOUR CRAWLTEK BUMPER ON A CJ YOU WILL NEED TO USE THE SUPPLIED 164 SPACERS (1" OD, 9/16" ID) BETWEEN THE FRAME RAIL AND BUMPER SHELL.





YOU'RE NOT DONE YET!

Thank you for your new CrawlTek Revolution purchase! Follow us on facebook for up to date coverage of new product releases. We love feedback, if you have any questions about the installation or parts were missing please contact us at sales-crawltek@ridefox.com or call us at 517.278.1039.

*Be sure to show off your jeep to the rest of the CrawlTek Revolution online.
Find us on facebook and instagram to keep up on new products, upcoming events and more action.
Tag us @crawltek for a chance to get featured*

