Warrior, Inc. 11100 SW Industrial Way Tualatin, Oregon 97062 (503) 691-8915 (503) 692-0364 FAX (888) 220-6861 Toll Free wp@warriorproducts.com

Warrior, Inc.

ADVENTURE RACK INSTALLATION INSTRUCTIONS WAR 832

1. Assemble your Adventure Rack complete but do not tighten the bolts.

2. Measure the distance, on your tire carrier if you are installing the rack on your carrier, between the upper mounting holes, and center this measurement, right to left, on the tailgate. This should center your rack on the back of your vehicle. If you have a flat surface on the back of your vehicle then you only need to center your rack left to right and top to bottom. The lower bracket will bolt to the area under the tailgate using self tapping screws.

3. Drill the upper mounting holes with a 3/8" drill bit on your swing away tire carrier or your tailgate.

4. Align assembled rack to upper drilled holes, and position lower bracket under tailgate. If you have a swing away tire carrier bracket extensions are available at no cost by calling the factory at 888-220-6861. Mark holes and drill a 1/8" pilot hole before you install the self tapping screws. Mount lower bracket with the offset up.

5. Mount Adventure Rack to lower brackets so that you can mark holes to be drilled in legs. Drill 4 holes on tailgate installation (2 on each leg); or 3 holes on swing away (2 holes on right leg and 1 hole on left leg.

- 6. Install rack with supplied hardware.
- 7. Tighten the bolts and check to be sure the **Adventure Rack** is secure on the rear of the vehicle. If you have bolted the rack only to your tailgate, a 50lb. weight limit is advised. ENJOY YOUR NEW RACK!

"Your Knight in Shining Armor!"