



Warrior Products, Inc.  
16850 SW Upper Boones Ferry Rd  
Ste. A  
Durham, OR 97224  
Phone (888) 220-6861  
Fax (503) 692-0364  
sales@warriorproducts.com

Protecting Your Adventure Lifestyle

---

# **ALUMINUM FULL DOOR INSERT PANEL** **INSTALLATION INSTRUCTIONS** **WAR 90750** **1976-1995 JEEP CJ7-YJ WRANGLER**

## **READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

1. Remove inner “grab handle” and window crank handle.
2. Remove the lower inner panel by prying with long screwdriver. Check to make sure that you did not leave any black plastic fasteners attached to the door.
3. Put the aluminum inner panel into place on the door making sure that it is under the OEM upper panel and centered on the door. At this time, mark all of the holes through the panel for drilling.
4. Remove the panel from the door. If you are going to use the “pop” rivets supplied, drill the holes using a 3/16” drill bit. If you choose to use sheet metal screws, use a drill bit appropriate for the size of screw you choose to use.
5. Install your new Warrior aluminum inner panel using the pop rivets supplied or sheet metal screws. Make sure that you have the panel situated under the OEM upper panel.
6. Reinstall the window crank handle and the grab handle removed in step #1. You can use Warrior Products’ optional aluminum grab handle (part # WAR 90756) if you prefer.