



WRANGLIATOR FRONT DRIVER DOOR BAG INSTALL

PATENT PENDING

Install Time: 5 Minutes w/ Screw Gun



**Tools Needed - T-30 & T-20
Torx Bit & Screw Gun or
Screw Driver**



**Match Up the Driver Side
Door to the Corresponding
Door Pouch**



**Unscrew the 2 Screws Under the
Arm Rest, Lift the Bag Sideways,
Slide a bolt through the First
Grommet & Reinstall the Bolt**



**Reinstall the 2nd Bolt the
Same Way**



**Finished View After Connecting
the Top**



**Connect the 1st Hook in the
Door Latch Slot**



**Connect the 2nd Hook in the
Door Limiting Strap Slot**



**Unscrew the 2 Screws from the
Bottom, Slide 1 through the 1st
Grommet, & Reinstall the Screw**



**Reinstall the 2nd Screw the
Same Way**



**Attach the Patch to the Velcro
& You're Done!**

